




MacBook Pro 17" Unibody Lower Case Replacement

Removing the lower case.

Written By: Andrew Bookholt



INTRODUCTION

Remove the lower case to access most components in your MacBook Pro 17" Unibody.



TOOLS:


- [Phillips #00 Screwdriver](#) (1)



PARTS:


- [MacBook Pro 17" Unibody \(Early/Mid 2009\) Lower Case](#) (1)

Step 1 — Lower Case



- Remove the following ten screws securing the lower case to the upper case:
 - Three 13.5 mm Phillips screws.
 - Seven 3 mm Phillips screws.

Step 2



- Wedge your fingers between the lower case and the vent, and lift upward to release the clips holding the lower case to the upper case.
- Remove the lower case.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-17 01:07:03 PM.